

# ELASTIKOTE® RESTORATION PROTOCOL: SINGLE PLY TPO

## ElastiKote 100

## 5 Year Warranty

### Existing Single Ply TPO Candidate

**Repair all Suspicious Tears, Cracks, and Seams  
w/ Labor Sav 'R Mastic**

**Labor Sav 'R  
Mastic  
as needed**

**6" Band of ElastiKote 100 (1.5 gal per sq)  
with 4" reinforcement scrim embedded  
in it over all seams**

**ElastiKote 100 Light Gray (1.50 gal per sq)**

**ElastiKote 100 White (1.50 gal per sq)**

### Preparation

Mechanically remove all loose gravel, dirt, etc. by vacuum, mechanical broom, power washing (1,000 – 1,500 psi) etc.

DO NOT incorporate high-pressure water into existing roof assembly

Clean areas as needed with ElastiKote Substrate Cleaner

Thoroughly rinse and remove all cleaner residues

Surface must be dry, clean, and free from dirt, loose rust and foreign substances

### Application

Complete Preparation Steps (above)

Apply 6" Band of ElastiKote 100 (1.5 gal per sq) with 4" reinforcement scrim embedded in it over all seams

Repair any surface tears, penetrations, expansion joints, curbs, etc. with Labor Sav'R Mastic (for defect gaps less than 3/16") at a minimum of 3/16" thickness and a minimum 4" wide or SEBS Mastic and reinforcement scrim (for defect gaps greater than 3/16")

Apply 1st coat of ElastiKote 100 (Light Gray) at 1.5 gal per sq

Apply final wear coat of ElastiKote 100 (White) at 1.5 gal per sq

**TOTAL COMPLETED MILS\_21 Dry Mils**