

# ELASTIKOTE® RESTORATION PROTOCOL: Single Ply KEE

## ElastiKote 1000

## 10 Year Warranty

### Existing Single Ply KEE Candidate

**Repair all Suspicious Tears, Cracks, and Seams  
w/ Labor Sav 'R Mastic**

**Labor Sav 'R  
Mastic  
as needed**

**S  
E  
A  
M**

**\*" Band of ElastiKote 1000 (1.5 gal per sq)  
k |h ( " fYbZfVW Yb|gW]a Yá VXXX  
]b |h|j YfU`gUa g'**

**ElastiKote 1000 Light Gray (1.50 gal per sq)**

**ElastiKote 1000 White (1.50 gal per sq)**

### Preparation

Mechanically remove all loose gravel, dirt, etc. by vacuum, mechanical broom, power washing (1,000 – 1,500 psi) etc.

DO NOT incorporate high-pressure water into existing roof assembly

Clean areas as needed with ElastiKote Substrate Cleaner

Thoroughly rinse and remove all clenaer residues

Surface must be dry, clean, and free from dirt, loose rust and foreign substances

### Application

Complete Preparation Steps (above)

Apply 6" Band of ElastiKot 1000 (1.5 gal per sq) with 4" reinforcement scrim embedded in it over all seams

Repair any surface tears, penetrations, expansion joints, curbs, etc. with Labor Sav'R Mastic (for defect gaps less than 3/16") at a minimum of 3/16" thickness and a minimum 4" wide or SEBS Mastic and reinforcment scrim (for defect gaps greater than 3/6")

Apply 1st coat of ElastiKote 1000 (Light Gray) at 1.5 gal per sq

Apply final wear coat of ElastiKote 1000 (White) at 1.5 gal per sq

**TOTAL COMPLETED MILS\_21 Dry Mills**