

ELASTIKOTE® RESTORATION PROTOCOL: SINGLE PLY PVC

ElastiKote 1000

10 Year Warranty

Existing Single Ply PVC Candidate

**Repair all Suspicious Tears, Cracks, and Seams
w/ Labor Sav 'R Mastic**

**Labor Sav 'R
Mastic
as needed**

**6" Band of ElastiKote 1000 (1.5 gal per sq)
with 4" reinforcement scrim embedded
in it over all seams**

ElastiKote 1000 Light Gray (1.50 gal per sq)

ElastiKote 1000 White (1.50 gal per sq)

Preparation

Mechanically remove all loose gravel, dirt, etc. by vacuum, mechanical broom, power washing (1,000 – 1,500 psi) etc.

DO NOT incorporate high-pressure water into existing roof assembly

Clean areas as needed with ElastiKote Substrate Cleaner

Thoroughly rinse and remove all cleaner residues

Surface must be dry, clean, and free from dirt, loose rust and foreign substances

Application

Complete Preparation Steps (above)

Apply 6" Band of ElastiKote 1000 (1.5 gal per sq) with 4" reinforcement scrim imbedded over all seams

Repair any surface tears, penetrations, expansion joints, curbs, etc. with labor Sav'R Mastic (for defect gaps less than 3/16") at a minimum of 3/16" thickness and a minimum of 4" wide or SEBS Mastic (for defect gaps greater than 3/16")

Apply 1st coat of ElastiKote 1000 (Light Gray) at 1.5 gal per sq

Apply final wear coat of ElastiKote 1000 (White) at 1.5 gal per sq

TOTAL COMPLETED MILS_21 Dry Mils