

ELASTIKOTE® RESTORATION PROTOCOL: SINGLE PLY TPO

ElastiKote 5000

10 Year Warranty

Existing Single Ply TPO Candidate

**Repair all Suspicious Tears, Cracks, and Seams
w/ Labor Sav 'R Mastic**

**Labor Sav 'R
Mastic
as needed**

***" Band of ElastiKote 5000 (1.5 gal per sq)
k jh ("fYbZfVW Ybhw)a Ya VXXX]b
]hij YFU`gUa g`**

ElastiKote 5000 Light Gray (1.50 gal per sq)

ElastiKote 5000 White (1.50 gal per sq)

Preparation

Mechanically remove all loose gravel, dirt, etc. by vacuum, mechanical broom, power washing (1,000 – 1,500 psi) etc.

DO NOT incorporate high-pressure water into existing roof assembly

Clean areas as needed with ElastiKote Substrate Cleaner

Thoroughly rinse and remove all cleaner residues

Surface must be dry, clean, and free from dirt, loose rust and foreign substances

Application

Complete Preparation Steps (above)

Apply 6" Band of ElastiKote 5000 (1.5 gal per sq) with 4" reinforcement scrim embedded in it over all seams

Repair any surface tears, penetrations, expansion joints, curbs, etc. with Labor Sav'R Mastic (for defect gaps less than 3/16") at a minimum of 3/16" thickness and a minimum 4" wide or SEBS Mastic and reinforcement scrim (for defect gaps greater than 3/16")

Apply 1st coat of ElastiKote 5000 (Light Gray) at 1.5 gal per sq

Apply final wear coat of ElastiKote 5000 (White) at 1.5 gal per sq

TOTAL COMPLETED MILS_21 Dry MilS