

# ELASTIKOTE® RESTORATION PROTOCOL: EPDM

## ElastiKote 1000

## 10 Year Warranty

### Existing EPDM Candidate

Repair all Surface Tears  
w/ BOND-TUF Tape

ElastiKote Rust Inhibitive/EPDM Primer (0.75 gal per sq)

\*" Band of Elastikote 1000 (1.5 gal per sq)  
with 4" Reinforcement Scrim Embedded in it

ElastiKote 1000 Light Gray (1.50 gal per sq)

ElastiKote 1000 White (1.50 gal per sq)

### Preparation

Mechanically remove all loose gravel, dirt, etc. by vacuum, mechanical broom, power washing (1,000 – 1,500 psi) etc.

DO NOT incorporate high-pressure water into existing roof assembly

Clean areas as needed with Elastikote Substrate Cleaner

Surface must be dry, clean, and free from dirt, loose rust and foreign substances

Repair surface tears etc. with Elastikote BOND-TUF TAPE

### Application

Complete Preparation Steps (above)

Apply Elastikote Rust Inhibitive/EPDM Primer at 0.75 gal per sq

Allow to dry at least 24 hours before applying additional applications

Apply 6" Band of Elastikote 1000 (1.5 gal per sq) with 4" reinforcement scrim embedded in it over all seams

Repair any remaining surface tears, penetrations, expansion joints, curbs, etc. (not done previously with BOND-TUF TAPE) with Labor Sav'R Mastic (for defect gaps less than 3/16") at a minimum of 3/16" thickness and a minimum of 4" wide or SEBS Mastic and reinforcement scrim (for defect gaps greater than 3/16")

Apply 1st coat of Elastikote 1000 (Light Gray) at 1.5 gal per sq

Apply final wear coat of Elastikote 1000 (White) at 1.5 gal per sq

**TOTAL COMPLETED MILS Q1 Dry Mil**