

ELASTIKOTE® RESTORATION PROTOCOL: EPDM

ElastiKote 5000

10 Year Warranty

Existing EPDM Candidate

**Repair all Surface Tears
w/ BOND-TUF Tape**

ElastiKote Rust Inhibitive/EPDM Primer (0.75 gal per sq)

**6" Band of Elastikote 5000 (1.5 gal per sq)
with 4" reinforcement scrim embedded in
it over all seams**

ElastiKote 5000 Light Gray (1.50 gal per sq)

ElastiKote 5000 White (1.50 gal per sq)

Preparation

Mechanically remove all loose gravel, dirt, etc. by vacuum, mechanical broom, power washing (1,000 – 1,500 psi) etc.

DO NOT incorporate high-pressure water into existing roof assembly

Clean areas as needed with Elastikote Substrate Cleaner

Surface must be dry, clean, and free from dirt, loose rust and foreign substances

Repair surface tears etc. with Elastikote BOND-TUF TAPE

Application

Complete Preparation Steps (above)

Apply Elastikote Rust Inhibitive/EPDM Primer at 0.75 gal per sq

Allow to dry at least 24 hours before applying additional applications

Repair any remaining surface tears, penetrations, expansion joints, curbs, etc. (not done previously with BOND-TUF TAPE) with Labor Sav'R Mastic (for defect gaps less than 3/16") at a minimum of 3/16" thickness and a minimum of 4" wide or SEBS Mastic and reinforcement scrim (for defect gaps greater than 3/16")

Apply 1st coat of Elastikote 5000 (Light Gray) at 1.5 gal per sq

Apply final wear coat of Elastikote 5000 (White) at 1.5 gal per sq

TOTAL COMPLETED MILS_21 Dry Mil

**Labor Sav'R
Mastic
as needed**

**S
E
A
M**